



# 4G WI-FI

## MF910 - 4G WI-FI HOTSPOT

### USER MANUAL

**ZTE** Copyright © 2014. All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on errors or update specifications without prior notice.

Version 1.1      September 2014

## CHECK YOUR SYSTEM REQUIREMENTS

Your 4G Wi-Fi Hotspot will connect to any Wi-Fi enabled device that supports Wi-Fi 802.11 b/g/n

A web browser is required to log in to your Wi-Fi Hotspot if you wish to make any configuration changes.

USB driverless connection is also supported for Windows (not RT), and MAC operating systems:

- Windows 8 (not including RT) / 7 / XP / Vista
- MAC OS X 10.5, 10.6, 10.7, 10.8, 10.9

Using the USB connection requires administrator rights to install and run the software.

We suggest you switch off your anti-virus software before connecting the hotspot

- In some cases protection software can prevent automatic installation.

It is possible to start the installation process manually by clicking the Autorun icon when it appears.

# GET TO KNOW YOUR DEVICE



Main Antenna

USB Charging

Antenna 2



SIM slot, Reset button


WPS

Power



# INSERT YOUR STANDARD SIZED SIM CARD

This device supports a Standard sized SIM card ONLY. Do not use a microSIM or SIM card adaptor which may damage your device.



1. Locate the SIM slot on the side of the device as shown above.
2. Open the SIM slot cover.
3. Insert your SIM card carefully as shown. The gold contacts must be facing up towards the screen with the cut corner towards the middle of the device.
4. Push the SIM fully home until it clicks into place.
5. For reference the Reset button is also located under the SIM slot cover.
6. Note: If you replace the SIM card with the device powered On, it will restart to read the new SIM card.

## IMPORTANT

This device supports a standard SIM or 2FF size.

Do not insert a micro SIM (3FF) or use a micro to mini SIM adaptor.

Use of 3<sup>rd</sup> party adaptors or non approved SIM card can damage your device.

Physical damage to the SIM card slot is not covered by warranty and will make your device unusable.


## TIPS

Remember to keep your plastic SIM card holder. It has a record of your SIM card details which you should keep handy.

The Reset button is located under the SIM slot cover. With the device switched on, press the hold the Reset button until the device restarts. A reset will restore all settings to factory default.

## CHARGE YOUR 4G WI-FI HOTSPOT

Connect your charger as shown. Take care to check the orientation of the charger lead and insert carefully into the charging port on the device.



- Only use the genuine charger and USB lead provided. Use of third party adaptors can damage your device.
- Typical charging time is 3-4 hours using the standard charger. Charging from a USB source (ie laptop) will take longer.
- During periods of high continuous activity with multiple users, high download rates or low network signal, charging by USB will not have sufficient current to charge the device. In this situation the battery will discharge so it is preferable to use the mains charger.
- Always insert and remove the charging lead with care and take care not to trip or pull on the lead harshly which could damage your device.
- Physical damage to the charging port is not covered by warranty.
- If the device is off while charging, press the power key as normal to switch on the device.
- The device can be left always on and connected to the charger if required.
- During periods of high continuous activity, high download rates or low network signal it is normal for the device to get hot.
- If the internal temperature of the device exceeds 45C then the battery cannot be charged due to safety limitations with Li-ion batteries.

## POWER UP YOUR 4G WI-FI HOTSPOT


Press and hold the Power key for 1-2 seconds until the display lights up.

The Wi-Fi hotspot will be available after about 20 seconds.

Check the condition of your Wi-Fi hotspot as shown by the display.

To switch your device Off, press and hold the power key for 5 seconds until the display starts to shut down.

## DISPLAY LAYOUT AND ICONS



During periods of inactivity it is normal for the display to turn off to preserve battery life. Press the power key briefly to confirm the device status if required.

## CONNECT DEVICES BY WI-FI

Your Wi-Fi hotspot can connect up to ten devices via Wi-Fi providing internet access for all your devices on the go.

- On the devices you wish to connect make sure Wi-Fi is switched on, then search for Wi-Fi devices.
- The Wi-Fi hotspot will show up as MF910-xxxxxx, click on this device to connect.
- Consult your device display and enter the default Password which is case sensitive. Any letters entered must be in upper case (capitals).

**Connection example for Windows 7 computer:**

1. On your task bar, next to the clock, click on the Network Interface icon
2. Click on the Wireless device called MF910-xxxxxx
3. Enter the password exactly as shown on the display observing the correct case for all letters
4. With Connect Automatically enabled your computer will remember the password and connect to your Wi-Fi device when it is on and in range.


**TIP**

It is also possible to connect via USB connection. See later for details.

## QUICK REFERENCES

Browser home page	http://192.168.0.1
Administrator login	password
Default SSID	MF910-xxxxxx This is displayed on the screen when the device is powered up. This can be switched off via the Settings > Wi-Fi menu
Default Wi-Fi Key	10 characters which are case sensitive. This is displayed on the screen when the device is powered up. This can be switched off via the Settings > Wi-Fi menu
Restore defaults	From the powered up state: Open the SIM slot on the device. Locate the Reset button and use a small object such as a pin or paperclip to press the button. Hold the Reset button for five seconds until the display shows 'Resetting' All passwords and settings will be restored to defaults and the hotspot will reboot. Use the default credentials on the screen to log back onto your device.

# LOG INTO THE WEB INTERFACE, MODEM LOGIN PAGE



- To access the modem configuration pages, open a browser and go to <http://192.168.0.1>
- The default login password is 'password'
- The first page shows a brief summary of the modem status:

Home Information SMS Phonebook Settings


### Device Information

No.	Host Name	MAC Address

• The table shows the information of connected wireless device(s).



## STATUS ICONS – WEB INTERFACE



### NO NETWORK ACCESS

- No Network Access can be any of the following conditions:
- A missing, faulty or incorrectly inserted SIM. Check you have inserted your SIM card the right way and fully pushed it home until it clicks into place.
- A PIN locked SIM card. Log into the web interface then enter the PIN code for your SIM card.
- A PUK locked SIM card. You may have entered the wrong PIN code too many times. Contact Spark to obtain your PIN Unlocking Key (PUK) code. Log into the web interface to enter your PUK and PIN code
- A PUK blocked SIM card. If you enter the wrong PUK code too many times the SIM card is permanently blocked. Contact your dealer to obtain a replacement SIM card.
- No Service, you are out of network coverage.



### INTERNATIONAL ROAMING

- The Roaming icon indicates you are connected to a foreign network.
- If Roaming is enabled on your data plan then roaming data charges will apply when connected via a roaming network.
- Contact your carrier to determine your data charges.

# INSTALLATION NOTES

- If you choose to install the device via the USB connection then a CDROM drive will pop up on first installation.
- Double-click Setup.exe to install the software.
- The installation will create a new shortcut on your desktop and a new program listing under Start-Programs.
- If you have problems with the installation please contact your supplier or see our website, [www.zte.co.nz](http://www.zte.co.nz) for more assistance and FAQ's.
- If you can't connect to the internet check your SIM card is inserted correctly, contact your service provider and check your account is active.
- To uninstall the application:  
Windows users: Start > SPARK 4G WI-FI > Uninstall

## MAC Users:

- Double click the Spark Modem CDROM on the desktop to install the modem.
- To uninstall, go to Applications and run Uninstall SPARK 4G WI-FI

# WEB INTERFACE GUIDE

## HOME TAB

The screenshot displays the 'Home' tab of a web interface. At the top, there is a green navigation bar with five tabs: 'Home' (selected), 'Information', 'SMS', 'Phonebook', and 'Settings'. Below the navigation bar, the main content area is divided into two sections. On the left, there is a status panel with a green 'X' icon, indicating a connection issue. It shows 'Current Data 0B', 'Duration 00:00:00', 'Upload 0b/s', and 'Download 0b/s', with a 'Connect' button below. On the right, there is a 'Device Information' section with a table. The table has three columns: 'No.', 'Host Name', and 'MAC Address'. The table is currently empty. Below the table, there is a green question mark icon and a note: '• The table shows the information of connected wireless device(s)'.

No.	Host Name	MAC Address

The home tab shows you how many users are connected and shows your network connection state and data usage summary.

- The device will automatically connect to the network so it shows the Disconnect button status by default.
- To change this behaviour press Disconnect first, then go to Settings > Network Settings > WAN Connection Mode, and select Manual.
- The number of devices connected to your Wi-Fi hotspot is displayed

## INFORMATION

Home	Information	SMS	Phonebook	Settings
Device Information	<h3>Device Information</h3>			
Statistics				
Data Limit Settings				
	SIM Card Number	— —		
	IMEI	864154021000013		
	IMSI	505013428407314		
	Signal Strength	-89 dBm		
	Wi-Fi Name (SSID)	MF910-27C3D9 <a href="#">Change</a>		
	Max. Access Number	14		
	Wi-Fi Performance	Long Wi-Fi Range <a href="#">Change</a>		
	LAN Domain	m.home		
	IP Address	192.168.0.1		
	WAN IP Address	— —		
	Software Version	T01		
	Firmware Version	T01		
	Hardware Version	MF910-1.0.0		

- View the device IMEI number, Signal strength and other details.
- Change the SSID
- Change the Wi-Fi Performance
  - Setting to Short Range will preserve battery life by reducing the Wi-Fi power but this will give you less reach and lower speeds.

# SMS

The screenshot displays the SMS application interface. At the top, there is a green navigation bar with five tabs: Home, Information, SMS (which is currently selected), Phonebook, and Settings. On the left side, there is a vertical menu with three items: Device SMS (highlighted in green), SIM SMS, and SMS Settings. The main content area is divided into two sections. The upper section features a text input field with the placeholder text "You can choose 5 contacts at most". Below this is a large, empty rectangular area intended for displaying a list of contacts. The lower section contains a text input field with the placeholder text "Please type message here". At the bottom left of this section, the text "(0785) (1/5)" is displayed. At the bottom right, there are two buttons: "Send" and "Back". At the very bottom of the screen, a small copyright notice reads "Copyright © 1998-2014 ZTE Corporation. All rights reserved | [Open Source Licenses](#)".

- Click in the top box to add Contacts
- You can enter Contact names in the Contacts field and the device will search and list applicable matches
- Click in the bottom box to type your message
- Press the Send button when done
- Threaded messages (messages sent and received to the same Contact) are displayed in the main panel.
- View SMS > SMS Settings to enable delivery reports and to check the SMS centre number (read from your SIM card)

# PHONEBOOK

The screenshot displays the Phonebook application interface. At the top, there is a navigation bar with tabs for Home, Information, SMS, Phonebook (selected), and Settings. On the left side, there is a sidebar menu with categories: All, Common, Family, Friend, and Colleague. The main content area is titled "Phonebook (219/600)". Below the title, there are action buttons: New, Send Message, Delete, and Delete All. A search bar is located on the right side of the main area. The central part of the interface is a table listing contacts. The table has columns for Name, Save Location, Mobile Number, and Group. Each row includes a checkbox on the left and a menu icon on the right. The contacts listed are: abc national, Adam, Adam & Judy Bo, adele, Alan Sutherland, Alan Sutherland, Alison, Alison, Alison home, and Alison home. At the bottom of the table, there is a pagination control showing page 1 of 22, and a "Page:" field with a "GO" button. At the very bottom of the page, there is a copyright notice: "Copyright © 1998-2014 ZTE Corporation. All rights reserved | [Open Source Licenses](#)".

<input type="checkbox"/>	Name	Save Location	Mobile Number	Group
<input type="checkbox"/>	abc national		0291111111	-
<input type="checkbox"/>	Adam		0401111111	-
<input type="checkbox"/>	Adam & Judy Bo		+2771111111	-
<input type="checkbox"/>	adele		0411111111	-
<input type="checkbox"/>	Alan Sutherland		0488111111	-
<input type="checkbox"/>	Alan Sutherland		0468111111	-
<input type="checkbox"/>	Alison		0411111111	-
<input type="checkbox"/>	Alison		0411111111	-
<input type="checkbox"/>	Alison home		0398111111	-
<input type="checkbox"/>	Alison home		0398111111	-


- Click Phonebook to view your SIM card contacts.
- Contacts are automatically read into the device but you can also copy and save on your device.
- Select the Contact to view more details, click Edit to make any changes, then select the Save location as Device.
- Contacts stored on the device can include additional fields.
- Select New to create a new contact and choose the save location as Device or SIM card.

## SETTINGS > QUICK SETTINGS


The screenshot shows a web interface for 'Quick Settings'. At the top, there is a navigation bar with tabs for 'Home', 'Information', 'SMS', 'Phonebook', and 'Settings'. Below this is a left-hand sidebar with a list of settings categories: 'Quick Settings' (highlighted), 'Network Settings', 'Wi-Fi Settings', 'Device Settings', 'Firewall', 'Router Settings', and 'Internet Wi-Fi'. The main content area is titled 'Quick Settings' and features a progress indicator with six steps: '1. Quick Setup', '2', '3', '4', '5', and '6'. A 'Next' button is located to the right of the progress indicator. Below the progress indicator, there is instructional text: 'The wizard will show you how to set up gateway safely: Click "Next" to continue, click "Previous" & "Next" to navigate, and click "Apply" to save settings.' and 'Set basic parameters in this wizard. For advanced parameters, set them in other menu.' At the bottom of the page, there is a footer with the text: 'Copyright © 1998-2014 ZTE Corporation. All rights reserved | [Open Source Licenses](#)'.

Step through the Quick Settings wizard to quickly review your current default settings.


# SETTINGS > NETWORK SETTINGS > DIAL UP SETTINGS:




The default connection setting will automatically connect to the network. The setting is greyed out if you are connected.

- Press the Disconnect button on the Home screen to change this setting and to enable International Roaming if required.
- If you make any changes, press Apply to save the change
- Manual: The device will allow for the manual selection of a network. This is generally used in a Roaming environment or if the device is struggling to connect automatically to the Network or allows you to connect to a different Roaming partner Network
- Press the Help icon  to get in context tips

# SETTINGS > NETWORK SELECTION:



- Network Selection is set to Automatic.
- Press the Disconnect button on the Home screen to change this setting if required.
- If you make any changes, press Apply to save the change
- Press the Help icon  to get in context tips.
- Normally there is no need to change these settings unless you change service provider.



# SETTINGS > APN:

Home Information SMS Phonebook Settings

Quick Settings  
Network Settings  
Dial-up Settings  
Network Selection  
APN  
Wi-Fi Settings  
Device Settings  
Firewall  
Router Settings  
Internet Wi-Fi

## APN

Current APN: TelecomData

Mode:  Auto  Manual

Profile: TelecomData

PDP Type: IPv4

Profile Name: TelecomData

APN: wap.telecom.co.nz

Authentication: NONE

User Name:


Password:

**?**


- You can set the Access Point Name (APN) on this page.
- Mode: If a fixed APN is provided by your service provider, select Manual APN. Otherwise, please select Auto APN, and the device will automatically obtain parameters.
- Profile: It contains one or more profile names.
- PDP Type: IPv4/IPv6/IPv4&IPv6.
- Profile Name: It refers to the name that you assign to the new profile.
- APN: Access Point Name. The APN contains 0-9 a-z A-Z, -, and it can't start with and end with -, or .
- Authentication: It is provided by your Internet Service Provider (ISP). Password Authentication Protocol (PAP) provides a simple method without encryption for the peer to establish its identity using a 2-way handshake. Challenge-Handshake Authentication Protocol (CHAP) is used to periodically verify the identity of the peer using a 3-way handshake.
- User Name: User name is used to obtain authentication from the ISP when the connection is established.
- Password: Password is used to obtain authentication from the ISP when the connection is established.
- Click "Set as default" to set this profile as the default profile.

- Press Disconnect on the Home screen to disconnect from the Network
- Your Wi-Fi Hotspot comes pre-installed with the standard Spark APNs. If you require an alternate APN please follow these steps:
  - Press Add New to create a new APN
  - Add the Profile Name, eg TelecomData
  - Enter the correct APN details eg wap.telecom.co.nz
  - Press Save to save your new APN
  - Press the Profile drop down box
  - Select the new APN profile name
  - Click on 'Set as default' to set the new APN as your preferred setting
- Normally there is no need to change these settings unless you change service provider or are instructed by your carrier.
- Consult your new carrier to obtain alternate APN details for your device.
- Press the Help icon **?** to get in context tips.


# SETTINGS > WI-FI SETTINGS > BASIC SETTINGS:




The SSID is the Wi-Fi Network Name for your device


- By default the SSID and Password is shown on the front screen. Select Disable on “Display SSID and Password On Screen” to hide this information.
- You can change the SSID to something more memorable or personal
- You can hide the SSID broadcast so unknown users will not even see your network
- You can change the security settings and password to suit your own preferences
- You can set the number of available connections between 1 and 10. The default setting is 10 users.
- Press Apply to save your changes
- Press the Help icon  to get in context tips

# SETTINGS > WI-FI SETTINGS > ADVANCED SETTINGS




- You can change the Wi-Fi settings to suit your personal choices or for specific requirements of your attached devices.
- Press Apply to save your changes
- Press the Help icon  to get in context tips


# SETTINGS > WI-FI SETTINGS > WPS




- WPS uses the push button on the front panel to connect seamlessly to supported devices.
- Press WPS to enable, compatible devices can connect to your Wi-Fi network without authorisation, or you can set a PIN if required.


- WPS is enabled for 2 minutes once pressed and the device LED's will flash to indicate WPS mode.
- If you have enabled PIN mode then you need to enter the same PIN on devices you wish to connect.
- Press the Help icon  to get in context tips


## SETTINGS > DEVICE SETTINGS > ACCOUNT MANAGEMENT



- Use the Account Management settings to change the administrator password if required.
- The default password is password. If you have changed and forgotten the password then you need to restore the device to factory defaults:
  1. With the device switched on open the SIM slot cover and locate the reset button next to the SIM slot.
  2. Using an item such as a paperclip or pin press and hold the “Reset” button for 5 seconds.
  3. The display will flash and the device will re-boot to factory default settings.
- Press the Help icon  to get in context tips

# SETTINGS > DEVICE SETTINGS > USIM PIN MANAGEMENT:



- Enter your current PIN code to change or disable the PIN
- If you make any changes, press Apply to save the change
- If you enter the incorrect PIN code three times in succession you will lock your SIM card.
- Contact your service provider to obtain your PUK code
- Press the Help icon  to get in context tips

## SETTINGS > DEVICE SETTINGS > RESET


- Press Reset to reset your device to factory defaults.

## SETTINGS > DEVICE SETTINGS > RESTART

- Press Restart to restart your device.


# SETTINGS > DEVICE SETTINGS > POWER SAVE

The screenshot shows the 'Settings' app interface. At the top, there are five tabs: 'Home', 'Information', 'SMS', 'Phonebook', and 'Settings'. The 'Settings' tab is selected. On the left side, there is a sidebar menu with the following items: 'Quick Settings', 'Network Settings', 'Wi-Fi Settings', 'Device Settings' (highlighted in green), '> Account Management', '> PIN Management', '> Reset', '> Restart', '> Power Save' (highlighted in green), '> Software Upgrade', 'Firewall', 'Router Settings', and 'Internet Wi-Fi'. The main content area is titled 'Wi-Fi Performance Settings'. It features a section for 'Wi-Fi Performance' with three radio button options: 'Short Wi-Fi Range - Best battery life', 'Medium Wi-Fi Range', and 'Long Wi-Fi Range' (which is selected). An 'Apply' button is located to the right of these options. Below this is a grey bar with a green question mark icon. The next section is titled 'Wi-Fi Sleep Settings'. It has a 'Sleep Time' label followed by a dropdown menu currently set to '10 Minutes'. An 'Apply' button is to the right. Below this is another grey bar with a green question mark icon.

- The default setting provides the greatest reach for your Wi-Fi signal.
- Setting to Short Range will preserve battery life by reducing the Wi-Fi power but this reduces the Wi-Fi signal range.
- If there is no Wi-Fi traffic detected then the device will switch off Wi-Fi as determined by the Wi-Fi sleep setting.
- Set Wi-Fi sleep time to Never Sleep to keep the Wi-Fi always on.
- Press the Help icon  to get in context tips

# SETTINGS > DEVICE SETTINGS > SOFTWARE UPDATE

The screenshot displays the 'Software Update' settings page. On the left, a navigation menu lists various settings categories, with 'Device Settings' highlighted. The main content area features a green header for 'Check New Version' and a 'Check' button. Below this, a 'Cycle Settings' section includes radio buttons for 'Auto-check New Version' (currently set to 'Enable') and a dropdown menu for 'Auto-check Cycle' (set to '15 days'). A checkbox option is present for 'Check this option, the device will Upgrade when roaming and you will incur roaming charges.', which is currently unchecked. An 'Apply' button is located at the bottom right of the settings area.

- With Check for New Version enabled you are notified on the device display and in the web user interface if there is an update available.
- You need to be in the Connected state to download new versions.
- Press the Update Now button to see if there are software updates for your device.
- Roaming Settings control if the device will update when roaming. This is disabled to reduce high data charges when roaming.
- Press the Help icon  to get in context tips

# SETTINGS > FIREWALL > PORT FILTERING

Home Information SMS Phonebook Settings

Quick Settings  
Network Settings  
Wi-Fi Settings  
Device Settings  
Firewall  
  > Port Filtering  
  > Port Forwarding  
  > UPnP  
  > DMZ  
Router Settings  
Internet Wi-Fi

## Port Filtering

MAC/IP/Port Filtering  Enable  Disable

Default Policy  Accepted  Dropped

Apply

?

### MAC/IP/Port Filtering Settings

IP Settings  IPv4  IPv6

MAC Address  (e.g., 00:1E:90:FF:FF:FF)

Source IP Address


Dest. IP Address

Protocol

Action  Accept  Drop

Comment \*

Apply


- Select Enable to turn on the Port Filtering settings
- You can apply filters based on MAC Address, Source IP Address, Destination IP Address and select the action to drop or accept the packets.
- Firewall settings are for advanced users and network administrators.
- Press the Help icon  to get in context tips




# SETTINGS > FIREWALL > PORT FORWARDING


The screenshot shows the 'Port Forwarding' settings page. At the top, there is a navigation bar with 'Home', 'Information', 'SMS', 'Phonebook', and 'Settings'. A sidebar on the left lists various settings categories, with 'Firewall' selected and 'Port Forwarding' highlighted. The main content area is titled 'Port Forwarding' and includes a 'Virtual Server Settings' section with 'Enable' selected. Below this is a 'Port Forwarding Settings' section with input fields for 'IP Address', 'Port Range', 'Protocol', and 'Comment'. An 'Apply' button is visible. At the bottom, there is a section for 'Current Virtual Servers in system' with a table header.

	IP Address	Port Range	Protocol	Comment
--	------------	------------	----------	---------

- Select Enable to turn on the port forwarding settings.
- Port forwarding can be used to allow a specific external server or computer access to devices located on your LAN side or to translate a specific incoming port into a different destination port.
- The destination port and address is on your local LAN side.
- Typical applications will be for on-line gaming requiring specific control and communications channels between the remote server and the local machine.
- Firewall settings are for advanced users and network administrators.
- Press the Help icon  to get in context tips


# SETTINGS > FIREWALL > UPNP SETTINGS



- Universal Plug and Play is a set of networking protocols that permits networked devices, such as personal computers, printers, Internet gateways, Wi-Fi access points and mobile devices to seamlessly discover each other's presence on the network and establish functional network services for data sharing, communications, and entertainment.
- UPnP is enabled by default on the LAN side (local) but if you require extra security you should disable this setting.
- UPnP is not enabled on the WAN (Network) side.
- Firewall settings are for advanced users and network administrators.
- Press the Help icon  to get in context tips.

## SETTINGS > FIREWALL > DMZ

The screenshot shows the 'DMZ Settings' page. At the top, there are navigation tabs: Home, Information, SMS, Phonebook, and Settings. On the left, a sidebar menu lists various settings categories, with 'Firewall' expanded to show 'Port Filtering', 'Port Forwarding', 'UPnP', and 'DMZ'. The main content area is titled 'DMZ Settings' and contains a radio button for 'DMZ Settings' with 'Enable' selected and 'Disable' unselected. Below this is an 'IP Address' input field, which is currently empty and has a red asterisk and the word 'Required' below it. An 'Apply' button is located at the bottom right of the settings area. A grey bar with a green question mark icon is visible at the bottom of the main content area.

- Enable the DMZ Setting to open up all ports from the WAN side (mobile network) to the LAN side for this particular allocated IP address.
- It is advisable to set a Static IP address for this device outside of the DHCP range eg 192.168.0.20
- Press the Help icon  to get in context tips.

## SETTINGS > FIREWALL > SYSTEM SECURITY

- Enable or Disable Remote Management (via WAN) and PING
- Firewall settings are for advanced users and network administrators.

# SETTINGS > ROUTER SETTINGS

Router Settings

IP Address \* 192.168.0.1

Subnet Mask \* 255.255.255.0


DHCP Server  Enable  Disable

DHCP IP Pool \* 192.168.0.100 - 192.168.0.200


DHCP Lease Time \* 24 hour(s)

Apply Cancel

?

- Control the IP Range for your network and enable or disable DHCP is required.
- Press the Help icon  to get in context tips

# SETTINGS > INTERNET WI-FI



- Enable the Wi-Fi router to connect to another Hotspot to share that internet connection.
- Internet Wi-Fi or the WAN side on your hotspot refers to the radio network connection.
- When the Internet Wi-Fi Switch option is enabled, it is not possible to disconnect the RF WAN side. The Disconnect button is greyed out. This is because the Wi-Fi Switch function over-rides the manual disconnect feature. When you fully connect to another local Wi-Fi hotspot then the WAN side data (RF connection to the network) is disabled.
- When you connect to another Wi-Fi hotspot your local WAN is disconnected and your Wi-Fi hotspot will receive its internet connection from the other hotspot and share this with all your connected devices.
- This could be useful at home where your wireless hotspot can connect to your home Wi-Fi when in range, and it can be used to extend your home Wi-Fi range by locating the portable hotspot in another location. The devices connected to your portable hotspot will get their internet connection from the other connected Wi-Fi hotspot, eg your home network.


## HELP

Click Help to access the system help

Click the Help icon  to see in context help

Go to [zte.co.nz](http://zte.co.nz) for FAQ's, product and warranty support

## EXTERNAL ANTENNA PORTS



- Signal strength can be improved by adding external antennas.
- It is preferred to use both ports for best quality reception and service.
- If you only have a single antenna then use the main port shown on the diagram above.
- The device supports dual TS9 connectors and dual antennas will provide better signal strength and higher data rates.
- Only use the correct antenna with the TS9 termination suitable for ZTE data products.
- Insert and remove the connections carefully. Do not pull on the cable to remove the connection. The antenna ports are delicate and need to be treated with care.
- Physical damage to the antenna port will render your device unusable and is not covered by the manufacturer's warranty.
- See your warranty card for full terms and conditions.

## TROUBLESHOOTING

If you have any problems with your connection or modem please consult the manual and check this section. If the problem still exists contact your service provider or check our website for more details at [zte.co.nz](http://zte.co.nz)

<b>Problem</b>	<b>Possible Causes</b>	<b>Suggested Solution</b>
The user interface doesn't start after the modem is plugged in.	PC configuration is not correct. (No autorun)	Start the program manually by going Start > Program Files or use the shortcut on the desktop.
The modem has no signal.	You have no network coverage.	Try moving location until you get good reception. Move the modem to a higher position or different orientation.
	Network coverage is low	Consider purchasing an external antenna. Use a TS9 connector.
SIM Card is locked	SIM card requires a PIN or PUK number. SIM is not inserted correctly	Contact your service provider to obtain the PIN or PUK key. Check the SIM card is inserted, is active and is a valid SIM.
Data connection failed.	You have no network coverage.	Try moving location until you get good reception.
The modem cannot connect to the internet when overseas	You don't have international roaming enabled on your plan.	Consult your service provider before you go overseas to enable roaming.
The buttons are greyed out or I cannot make changes	You are in the Connected state, disconnect first.	Many settings update require you to disconnect from the network first. Press Disconnect on the Home page to end your data session, then you can make your required changes.

## PRECAUTIONS AND SAFETY INFORMATION

- Some electronic devices are susceptible to electromagnetic interference. The modem is a transmitting device and may cause interference to sensitive electronic equipment such as audio systems, vehicle systems and medical equipment. Please consult the manufacturer of the other device before using the modem.
- Operating of laptop or desktop PCs with the modem may interfere with medical devices like hearing aids and pacemakers. Please keep the modem more than 20 centimetres away from such medical devices. Turn the modem off if necessary. Consult a physician or the manufacturer of the medical device before using the modem near such devices.
- Be aware of regulations when using the modem at places such as oil refineries or chemical factories, where there are explosive gases or explosive products being processed. Turn off your modem as instructed.
- Don't touch the antenna area unnecessarily whilst connected. This can affect your modem performance and reduce the signal quality.
- Store the modem out of the reach of children. The modem may cause injury or get damaged.
- The modem contains sensitive electronic circuitry. Do not expose the modem to any liquids, high temperatures or shock.
- Only use original accessories or accessories that are authorised by the manufacturer. Using unauthorised accessories may affect your modem's performance or damage your modem.
- Avoid using the modem in areas that emit electromagnetic waves or in enclosed metallic structures eg lifts.
- The modem is not waterproof. Please keep it dry and store it in a cool, dry place.
- Don't use the modem immediately after a sudden temperature change eg from an air conditioned environment to high temperature and humidity outside. In such cases there could be condensing moisture inside the modem which can cause internal damage. Unplug the modem and leave it for 30 minutes before use.
- Always handle the modem with care. Be careful not to drop or bend the modem.
- There are no user serviceable parts inside the modem. Unauthorised dismantling or repair will void the warranty.
- Take care when connecting and removing an external antenna. The correct adaptor (TS9) must be used and the ports are delicate and must be handled with care. Do not pull or tug on the antenna leads and take care not to trip over them



when plugged in.

- Physical damage to the antenna ports will render your device unusable and is not covered by the manufacturer's warranty.
- The internal battery is not replaceable by the end user. Return to your service centre for repair.
- Do not disassemble the case to change the battery, do not disassemble or short circuit the battery terminals.
- Do not dispose of the unit in a fire, the internal battery may explode.
- At the end of life of the equipment, return the product to a suitable recycling agent such as Mobile Muster.

## RF SAFETY INFORMATION

The Wi-Fi modem has internal antennas. For optimum performance with minimum power consumption do not shield the device or cover with any object. Covering the antennas affects signal quality and may cause the modem to operate at a higher power level than needed.

## RADIO FREQUENCY ENERGY

The Wi-Fi modem is a low-power radio transmitter and receiver. When switched on it intermittently transmits radio frequency (RF) energy (radio waves).

The transmit power level is optimized for best performance and automatically reduces when there is good quality reception.

Maximum power is only used at the edge of network coverage so under most circumstances the power output is very low.

Under poor network conditions the modem transmits at a higher power level and may get hot.

## DECLARATION OF CONFORMITY – SPECIFIC ABSORPTION RATE (SAR)

The Wi-Fi modem is designed to be used in close proximity to the body. We declare that the product detailed in this manual, and in combination with our accessories, conform with the essential requirements of Section 134 (1) (g) of the New Zealand Radiocommunications Act 1989 when used at a distance of not less than 10mm from the body. The worst case SAR result is 1.458W/Kg (10g average) with 10mm spacing in the Body position. The limit is 2.0W/Kg

**Z1196**

## TECHNICAL SPECIFICATIONS

---

Network compatibility	LTE 700, 900, 1800, 2100, 2600 MHz UMTS 850, 900, 2100 MHz GSM 850, 900, 1800, 1900 MHz
Dimensions	100 x 62.8 x 13.5mm. Approx 120g
Data Rates*	LTE download speeds up to 150Mb/s LTE upload speeds up to 50Mb/s HSPA+ Downlink up to 42Mb/s HSDPA Mode up to 21.6Mb/s HSUPA Mode up to 5.76Mb/s
Battery	2300mAh internal battery, non user replaceable
Operating Time**	Up to 8 hours operating time. Up to 300 hrs in standby mode with Wi-Fi off.
Voltage	5V
Current	Resting: 100mA rms Max: 500mA rms
Operating systems	Any Wi-Fi enabled device, 802.11b/g/n Windows 8 (not RT), 7, XP SP3, Vista MAC OS X 10.6, 10.7, 10.8, 10.9
Antenna ports	Dual TS9 connectors
Temperature	-5°C to +45°C

\* Download speeds will vary due to distance from the cell, local conditions, user numbers, file source, hardware, software and other factors.

\*\* Operation and Standby times depend on a number of conditions and are measured in ideal conditions.